


# How to connect via HDMI

If you have any trouble with the operation, please contact us.  
extension :40

**1**



Hold the card key over the card key unit. The reverse side of the card does not matter. A short tone sounds and the rack is unlocked.

**2**



Open the rack and turn on the main power. Turn off the main power when you are finished.

**3**



When the main power is turned on, the control panel on the desk is activated. **All Start** activates all three screens, projectors, and blinds at once; **SETUP** is an individual setting.

**4**



When using **SETUP**, activate the screen(スクリーン), projector(プロジェクター), and blinds(ブラインド) individually.

**5**



When the projector is turned off, it stops working for about 5 minutes. If you want to hide the screen temporarily, we recommend blacking out the screen without turning off the power.

**6**



Connect an HDMI cable to your computer or tablet.



Please bring any necessary items such as conversion connectors.

**7**



Select the **HDMI** of the projector you wish to display.

## How to end


- Exit the control panel. 「終了画面」 → 「YES」
- Turn off the main power.
- Disconnect the HDMI cable and put it back in place.
- Close the rack door.

Be careful not to pinch your fingers.

## If the screen does not appear on the projector

### Windows

[Windows]+[P] to display the screen below. Make sure it is a duplicate (複製).



### Mac

Try setting the display resolution to full HD.

Full HD : 1920 × 1080

If only the desktop is displayed, try checking the Mirroring checkbox.

# When there is no sound coming out of the classroom speakers.



**HDMI outputs audio as well as video. The audio comes from the classroom speakers.**

**If the connected device does not recognize HDMI properly, sound may not be output. Try VGA + audio mini-pin instead.**

## What to do when there is no sound

**First, check that the device (e.g., computer) to which you are connecting produces sound.**

- Is the volume on your computer or software muted?
- Turn up the volume on your computer and software whenever possible.



- Unplug and plug the HDMI cable to see if it improves.



- Is the "volume" on the control panel turned down low? Try adjusting the volume.

- If you cannot find the problem anywhere and there is no sound, try restarting the computer or other equipment.

**If there is no sound coming from the computer without an HDMI cable connected, the problem may be with the computer. Please connect the HDMI cable to the computer after the sound is output from the computer.**